

# 3 Port Solenoid Valve


## VQZ100/200/300 Series

Metal Seal

Rubber Seal


Power consumption: **0.35 w / 0.9 w**  
 (Standard)  
 (High pressure type,  
 High speed response type)

CE  
 [Option]



### Compact, High Flow

Series	Valve width (mm)	Flow rate characteristics	
		Metal seal C [dm <sup>3</sup> /(s·bar)]	Rubber seal C [dm <sup>3</sup> /(s·bar)]
Body ported	VQZ100	—	0.56 (Poppet)
	VQZ200	1.3	1.7
	VQZ300	2.4	3.0
Base mounted	VQZ100	—	1.0 (Poppet)
	VQZ200	2.0	3.0
	VQZ300	3.2	4.1



SYJ

VQZ

VP














VG

VP3

# Metal Seal / Rubber Seal 3 Port Solenoid Valve


## VQZ100/200/300

### Solenoid Valve Variations

		Sonic conductance C [dm <sup>2</sup> /(s·bar)]		Type of actuation	Voltage	Electrical entry	Light/Surge voltage suppressor	Manual override	
Body ported	3 port	<b>VQZ100</b>  P.1222	Metal — Rubber (Poppet) 0.56						
		<b>VQZ200</b>  P.1223	1.3 1.7				Grommet (G) 		
		<b>VQZ300</b>  P.1223	2.4 3.0	 2(A) (R)3 1(P) N.C.	(Standard) 12 VDC 24 VDC	L-type plug connector (L) 	With light/surge voltage suppressor	Non-locking push type (Tool required)	
Base mounted	3 port	<b>VQZ100</b>  P.1238	Metal — Rubber (Poppet) 1.0	 2(A) (R)3 1(P) N.O. (Except VQZ100)	(Option) 100 VAC 200 VAC 110 VAC 220 VAC	M-type plug connector (M) 	L-type plug connector (L) M-type plug connector (M)		
		<b>VQZ200</b>  P.1239	2.0 3.0			DIN terminal (Y) 	DIN terminal (YZ) (Except VQZ100)	Locking type (Tool required)	
		<b>VQZ300</b>  P.1239	3.2 4.1			(Except VQZ100) 			

## Manifold


### Body Ported



P.1229

Series	Base model	Piping direction	Piping specifications		Applicable solenoid valve	Applicable stations
			Bore size			
			1(P), 3(R)	2(A)		
VQZ100	VV3QZ12-□□□	Top	Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ115	2 to 20 stations
VQZ200	VV3QZ22-□□□	Top	Rc 1/8	C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ2□2	2 to 20 stations
VQZ300	VV3QZ32-□□□	Top	Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3□2	2 to 20 stations

### Base Mounted




P.1245

Series	Base model	Piping direction	Piping specifications		Applicable solenoid valve	Applicable stations
			Bore size			
			1(P), 3(R)	2(A)		
VQZ100	VV3QZ15-□□□	Side/top	Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ115	2 to 20 stations
VQZ200	VV3QZ25-□□□	Side	Rc 1/4	C4 (for ø4) C6 (for ø6) C8 (for ø8) Rc 1/8	VQZ2□5	2 to 20 stations
VQZ300	VV3QZ35-□□□	Side	1(P) port Rc 3/8 3(R) port Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3□5	2 to 20 stations

## Manifold Options

### Body Ported


Blanking plate assembly  
VVQZ100-10A-5  
(for VQZ100)  
VVQZ200-10A-2  
(for VQZ200)  
VVQZ300-10A-2  
(for VQZ300)



P.1235

Blanking plug


KQ2P-23  
KQ2P-04  
KQ2P-06  
KQ2P-08  
KQ2P-10



P.1235


DIN rail

AXT100-DR-□



P.1235


Silencer  
(for EXH port)



P.1235

### Base Mounted


Blanking plate assembly  
VVQZ100-10A-5  
(for VQZ100)  
VVQZ200-10A-5  
(for VQZ200)  
VVQZ300-10A-5  
(for VQZ300)



P.1252

Blanking plug

KQ2P-23  
KQ2P-04  
KQ2P-06  
KQ2P-08  
KQ2P-10



P.1252


DIN rail

AXT100-DR-□



P.1252

Silencer  
(for EXH port)



P.1252

Port plug

VVQZ100-CP (for VQZ100)



P.1252

SYJ

VQZ

VP

VG

VP3

Body Ported  
Plug Lead Unit

# 3 Port Solenoid Valve

# VQZ100/200/300 Series

## Single Unit




[Option]  
Note) CE-compliant:DC type only.

### VQZ100 / How to Order Valve

VQZ 1 1 5 [ ] - 5 M [ ] 1 - C6 - PR [ ] - [ ]

Series  
1 VQZ100 body width 10 mm



Body type

Function

Symbol	Specifications	DC	AC
Nil	Standard	(0.35 W)	Note 3)
K Note 1)	High pressure type	(0.9 W)	—
R Note 1, 2)	External pilot type		
KR Note 1, 2)	High pressure/External pilot type	(0.9 W)	—

Note 1) Semi-standard  
Note 2) For details on external pilot type, refer to page 1236.  
Note 3) For AC specification power consumption, refer to page 1224.

**Caution**  
Use standard (DC) specification for continuous duty.

Coil voltage

		CE-compliant
1	100 VAC (50/60 Hz)	—
2	200 VAC (50/60 Hz)	—
3	110 VAC (115 VAC) (50/60 Hz)	—
4	220 VAC (230 VAC) (50/60 Hz)	—
5	24 VDC	●
6	12 VDC	●


CE-compliant

Nil	—
Q	CE-compliant

Note) DC type only.

Option

Nil: None  
F: With bracket




Port size [2(A) port]

C3	ø3.2 One-touch fitting
C4	ø4 One-touch fitting
C6	ø6 One-touch fitting
M5	M5 thread (Replaceable type)

Note) For inch size One-touch fittings, refer to page 1236.

Manual override

Nil: Non-locking push type  
B: Locking type (Tool required)



Electrical entry

G: Grommet (DC specification)	L: L-type plug connector with lead wire	LO: L-type plug connector without connector	M: M-type plug connector with lead wire	MO: M-type plug connector without connector
	With light/surge voltage suppressor	With light/surge voltage suppressor	With light/surge voltage suppressor	With light/surge voltage suppressor

Note) Standard lead wire length: 300 mm

Note) For applicable One-touch fitting and silencer models for this valve series, refer to page 1258.

Note) When placing an order for body ported solenoid valve as a single unit, mounting screw for manifold and gasket are not attached. Order them separately, if necessary. (For details, refer to page 1237.)

## VQZ200/300 / How to Order Valve



Made to Order

(For details, refer to pages 1224 and 1255.)

Note) AC-type models that are CE-compliant have DIN terminals only.



**VQZ 2 1 2 - 5 M - 1 - C6 - - -**

**Series**

2	VQZ200 body width 15 mm
3	VQZ300 body width 18 mm

**Type of actuation**

1	N.C. 2(A)	Metal seal
	(R)3 1(P)	
2	N.O. 2(A)	Metal seal
	(R)3 1(P)	
3	N.C. 2(A)	Rubber seal
	(R)3 1(P)	
4	N.O. 2(A)	Rubber seal
	(R)3 1(P)	

**Body type**

2	Body ported
---	-------------

**Function**

Symbol	Specifications	DC	AC
Nil	Standard	(0.35 W) Note 3)	Note 3)
B Note 1)	High speed response type	(0.9 W)	—
K Note 1)	High pressure type (Metal seal type only)	(0.9 W)	—
R Note 1, 2)	External pilot type	○	○
BR Note 1, 2)	High speed response/External pilot type	(0.9 W)	—
KR Note 1, 2)	High pressure/External pilot type (Metal seal type only)	(0.9 W)	—

**Caution**  
Use standard (DC) specification for continuous duty.

**Coil voltage**

1	100 VAC (50/60 Hz)
2	200 VAC (50/60 Hz)
3	110 VAC [115 VAC] (50/60 Hz)
4	220 VAC [230 VAC] (50/60 Hz)
5	24 VDC
6	12 VDC

Note) For applicable One-touch fitting and silencer models for this valve series, refer to back page 1258.  
Note) When placing an order for body ported solenoid valve as a single unit, mounting screw for manifold and gasket are not attached. Order them separately, if necessary. (For details, refer to page 1237.)

**CE-compliant**


Nil	—
Q	CE-compliant

Note) AC-type models that are CE-compliant have DIN terminals only.

**IP65 compliant**

Nil	—
W Note)	Compliant


Note) VQZ200/300 DIN terminal rubber seal only (except external pilot). For details on IP65 enclosure, refer to page 1236.



**Port size [2(A) port]**

Symbol	Port size	VQZ200	VQZ300
C4	ø4 One-touch fitting	○	—
C6	ø6 One-touch fitting	○	○
C8	ø8 One-touch fitting	—	○
C10	ø10 One-touch fitting	—	○
M5	M5 thread	○	—
O2	Rc 1/4	—	○

Note) For inch size One-touch fittings and option thread type, refer to page 1236.




**Electrical entry**

	G: Grommet (DC specification)	L: L-type plug connector with lead wire	LO: L-type plug connector without connector	M: M-type plug connector with lead wire	MO: M-type plug connector without connector
	With light/surge voltage suppressor	With light/surge voltage suppressor	With light/surge voltage suppressor	With light/surge voltage suppressor	With light/surge voltage suppressor
CE-compliant	AC	—	—	—	—
	DC	●	●	●	●
	Y: DIN terminal	YO: DIN terminal without connector	YZ: DIN terminal	YOS: DIN terminal without connector (DC specification)	YS: DIN terminal (DC specification)
	—	—	With light/surge voltage suppressor	With surge voltage suppressor	With surge voltage suppressor
CE-compliant	AC	●	●	—	—
	DC	●	●	●	●

Note 1) Standard lead wire length: 300 mm  
Note 2) For AC voltage valves there is no "S" type. It is already built-in to the rectifier circuit.

SYJ  
VQZ  
VP  
VG  
VP3

# VQZ100/200/300 Series



## Specifications

Valve construction	Metal seal	Rubber seal	VQZ100 (Poppet seal)
Fluid	Air		
Max. operating pressure (MPa)	0.7 (High pressure type: 1.0)	0.7	0.7 (High pressure type: 1.0)
Min. operating pressure (MPa)	0.1	0.15	0.15
Ambient and fluid temperature (°C)	-10 to 50 (No freezing)		
Max. operating frequency (Hz)	20	5	20
Pilot exhaust method	Individual exhaust		Common exhaust <sup>Note 1)</sup>
Lubrication	Not required		
Manual override	Push type, Locking type (Tool required)		
Mounting orientation	Free		
Impact/Vibration resistance (m/s <sup>2</sup> ) <sup>Note 2)</sup>	150/30		
Enclosure <sup>*</sup>	Dustproof (DIN terminal: IP65 <sup>Note 3)</sup> )		

\* Based on IEC60529

Note 1) When using body ported type as a single unit, the individual exhaust is used.

Note 2) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Value in the initial state)

Vibration resistance: No malfunction occurred in one sweep test between 45 and 2000 Hz. Test was performed to axis and right angle directions of the main valve and armature when pilot signal is ON and OFF. (Value in the initial state)

Note 3) When IP65 compliant DIN terminals are selected: VQZ□□□□□□□□□□

## Solenoid Specifications

### Semi-standard Specifications

High speed response type
High pressure type (Metal seal type only)
External pilot type*

\* For details on external pilot type, refer to page 1236.



**Made to Order**  
(For details, refer to page 1255.)

Symbol	Description
X30	Pilot valve common exhaust
X90	Main valve fluororubber
X113	All fluororubber

Electrical entry		Grommet (G)		M-type plug connector (M)	
		L-type plug connector (L)		DIN terminal (Y)	
		G, L, M		Y	
Coil rated voltage (V)	DC	24, 12			
	AC 50/60 Hz	100, 110, 200, 220*			
Allowable voltage fluctuation		±10% of rated voltage*			
Power consumption (W)	DC	Standard	0.35 [(With light: 0.4 (DIN terminal with light: 0.45)]		
		High speed response, high pressure	0.9 [(With light: 0.95 (DIN terminal with light: 1.0)]		
Apparent power (VA) <sup>*</sup>	AC	100 V	0.78 (With light: 0.81)	0.78 (With light: 0.87)	
		110 V [115 V]	0.86 (With light: 0.89) [0.94 (With light: 0.97)]	0.86 (With light: 0.87) [0.94 (With light: 1.07)]	
		200 V	1.18 (With light: 1.22)	1.15 (With light: 1.30)	
		220 V [230 V]	1.30 (With light: 1.34) [1.42 (With light: 1.46)]	1.27 (With light: 1.46) [1.39 (With light: 1.60)]	
Surge voltage suppressor		Varistor			
Indicator light		LED (Neon light when AC with DIN terminal)			

\* In common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC.

\* For 115 VAC and 230 VAC, the allowable voltage is -15% to +5% of rated voltage.

## Flow Rate Characteristics

Series	Valve construction	Model	Flow rate characteristics						Response time (ms) <sup>Note 1)</sup>				Weight (g)	
			1 → 2 (P → A)			2 → 3 (A → R)			Standard: 0.35 W	High speed response: 0.9 W	High pressure: 0.9 W	AC		
			C [dm <sup>3</sup> /(s·bar)]	b	Cv	C [dm <sup>3</sup> /(s·bar)]	b	Cv						
VQZ100	N.C. valve	Poppet	VQZ115	0.59	0.44	0.17	0.56	0.30	0.14	10 or less	—	13 or less	22 or less	24
VQZ200	N.C. valve	Metal seal	VQZ212	1.2	0.21	0.30	1.3	0.24	0.33	22 or less	14 or less	18 or less	34 or less	57
		Rubber seal	VQZ232	1.6	0.33	0.39	1.7	0.37	0.45	22 or less	15 or less	—	36 or less	
	N.O. valve	Metal seal	VQZ222	1.2	0.25	0.31	1.3	0.20	0.31	22 or less	14 or less	18 or less	34 or less	
		Rubber seal	VQZ242	1.6	0.36	0.40	1.7	0.36	0.45	22 or less	15 or less	—	36 or less	
VQZ300	N.C. valve	Metal seal	VQZ312	2.7	0.18	0.62	2.4	0.28	0.56	22 or less	17 or less	22 or less	34 or less	93
		Rubber seal	VQZ322	3.5	0.34	0.87	3.0	0.33	0.72	33 or less	25 or less	—	57 or less	
	N.O. valve	Metal seal	VQZ322	2.6	0.21	0.59	2.2	0.16	0.49	22 or less	17 or less	22 or less	34 or less	
		Rubber seal	VQZ342	3.5	0.38	0.88	2.9	0.27	0.69	33 or less	25 or less	—	57 or less	

Note 1) Based on JIS B 8419: 2010 (Supply pressure: 0.5 MPa; with light/surge voltage suppressor: clean air)



Response time values will change depending on pressure and air quality.

Note 2) Weight for threaded connection

1224

## Construction

### VQZ100 Poppet type







### Component Parts





No.	Description	Material	Note
1	Body	Resin	
2	Spool valve	Aluminum/HNBR	
3	Pilot valve assembly	—	
4	P. R. plate	Resin/Aluminum	VQZ100-12A (Standard) VQZ100-12B (External pilot type) <sup>Note)</sup>

Note) It is not possible to change the standard product to external pilot type, and vice versa.

### VQZ200/300 Metal seal type



### Rubber seal type



SYJ

VQZ

VP

VG

VP3

### Component Parts

No.	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool, Sleeve	Stainless steel	Metal seal
	Spool valve	Aluminum/HNBR	Rubber seal
3	Piston	Resin	
4	Pilot valve assembly	—	



Note) For "How to Order Pilot Valve Assembly", refer to page 1237.

# VQZ100/200/300 Series


## Dimensions: VQZ100

### Single Unit

Grommet (G): VQZ115□-□G□1-C3, C4, C6-PR




Note) For bracket assembly part no., refer to page 1237.




Note) For One-touch fittings for P/R port and silencer part no., refer to page 1258.

### VQZ115□-□G□1-M5-PR




### L-type plug connector (L): VQZ115□-□L□1-C3, C4, C6-PR



Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ]: AC

### M-type plug connector (M): VQZ115□-□M□1-C3, C4, C6-PR





Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ]: AC



## Dimensions: VQZ200


### Single Unit

#### Grommet (G): VQZ2□□-□G□1-C4, C6




Note) For bracket assembly part no., refer to page 1237.

#### VQZ2□□-□G□1-M5




Note) For One-touch fittings for P/R port and silencer part no., refer to page 1258.

#### L-type plug connector (L): VQZ2□□-□L□1-C4, C6




Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ]: AC

#### M-type plug connector (M): VQZ2□□-□M□1-C4, C6



Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ]: AC

#### DIN terminal (Y): VQZ2□□-□Y□□1-C4, C6



Unless otherwise indicated, dimensions are the same as Grommet (G).

SYJ

VQZ

VP

VG



VP3

# VQZ100/200/300 Series

## Dimensions: VQZ300


### Single Unit

#### Grommet (G): VQZ3□2□-□G□1-C6, C8, C10




Note) For bracket assembly part no., refer to page 1237.

#### VQZ3□2□-□G□1-02




#### L-type plug connector (L): VQZ3□2□-□L□1-C6, C8, C10




Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ] : AC

#### DIN terminal (Y): VQZ3□2□-□Y□1-C6, C8, C10



Unless otherwise indicated, dimensions are the same as Grommet (G).

#### M-type plug connector (M): VQZ3□2□-□M□1-C6, C8, C10



Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ] : AC

Body Ported

Plug Lead Unit

# 3 Port Solenoid Valve

# VQZ100/200/300 Series


## Manifold Connector Kit



[Option]


Note) For CE-compliant models, DC type only.

### VQZ100 / How to Order Manifold



Note) For 1(P), 3(R) of optional thread type, refer to page 1236.

### VQZ100 / How to Order Valve



Note 1) Semi-standard  
Note 2) For details on external pilot type, refer to page 1236.  
Note 3) For AC specification power consumption, refer to page 1224.



**Caution**  
Use standard (DC) specification for continuous duty.

Coil voltage	CE-compliant
1 100 VAC (50/60 Hz)	—
2 200 VAC (50/60 Hz)	—
3 110 VAC [115 VAC] (50/60 Hz)	—
4 220 VAC [230 VAC] (50/60 Hz)	—
5 24 VDC	●
6 12 VDC	●

Note) When placing an order for body ported solenoid valve as a single unit, mounting screw for manifold and gasket are not attached. Order them separately, if necessary. (For details, refer to page 1237.)

SYJ

VQZ

VP

VG

VP3


# VQZ100/200/300 Series

## VQZ200/300 / How to Order Manifold




**Made to Order**  
(For details, refer to page 1255.)

Note) AC-type models that are CE-compliant have DIN terminals only.



## VQZ200/300 / How to Order Valve



Note 1) Semi-standard  
Note 2) For details on external pilot type, refer to page 1236.  
Note 3) For AC specification power consumption, refer to page 1224.



**Caution**  
Use standard (DC) specification for continuous duty.

**Coil voltage**

1	100 VAC (50/60 Hz)
2	200 VAC (50/60 Hz)
3	110 VAC [115 VAC] (50/60 Hz)
4	220 VAC [230 VAC] (50/60 Hz)
5	24 VDC
6	12 VDC


### Electrical entry

Symbol	Electrical entry	Light/surge voltage suppressor	CE-compliant	
			AC	DC
G	Grommet (DC specification)	None	—	●
L	L-type plug connector with lead wire	Yes	—	●
LO	L-type plug connector without connector		—	●
M	M-type plug connector with lead wire		—	●
MO	M-type plug connector without connector	None	—	●
Y	DIN terminal		●	●
YO	DIN terminal without connector		●	●
YZ	DIN terminal	Yes	●	●
YS (Note 2)	DIN terminal (DC specification)	Yes (Without light)	—	●
YOS (Note 2)	DIN terminal without connector (DC specification)		—	●

Note 1) Standard lead wire length: 300 mm  
Note 2) For AC voltage valves there is no "S" type. It is already built-in to the rectifier circuit.

Note) When placing an order for body ported solenoid valve as a single unit, mounting screw for manifold and gasket are not attached. Order them separately, if necessary. (For details, refer to page 1237.)

## Manifold Specifications



Series	Base model	Piping specifications			Applicable solenoid valve	Applicable stations	Manifold base weight (g)
		Piping direction	Port size				
			1(P), 3(R)	2(A)			
VQZ100	VV3QZ12-□□□	Top	Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ115	2 to 20 stations	2 stations: 83 Addition per station: 19
VQZ200	VV3QZ22-□□□	Top	Rc 1/8	C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ2□2	2 to 20 stations	2 stations: 68 Addition per station: 20
VQZ300	VV3QZ32-□□□	Top	Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3□2	2 to 20 stations	2 stations: 114 Addition per station: 37

## How to Order Manifold Assembly (Example)

VV3QZ22-05C ..... 1 set (C kit 5-station manifold base part no.)

\* VVQZ200-10A-2 ... 1 set (Blanking plate assembly part no.)

\* VQZ212-5M1-C6 ... 4 sets (N.C. type part no.)

→ The asterisk denotes the symbol for assembly. Prefix it to the part nos. of the solenoid valve, etc.

→ Enter in order starting from the first station on the D side.

Add the valve and option part number under the manifold base part number.  
When entry of part numbers becomes complicated, indicate by the manifold specification sheet.

- SYJ
- VQZ
- VP
- VG
- VP3

# VQZ100/200/300 Series

## Dimensions: VQZ100

### VV3QZ12- Stations C

#### Grommet (G)

U side

D side


One-touch fitting

[2(A) port]


Applicable tubing O.D.:  $\phi 3.2$ ,  $\phi 1/8"$

$\phi 4$ ,  $\phi 5/32"$

$\phi 6$ ,  $\phi 1/4"$




(Station n) ----- (Station 1)




The dashed lines indicate the DIN rail mounting [-D].

#### M5




#### L-type plug connector (L)



Unless otherwise indicated, dimensions are the same as Grommet (G).

[ ] : AC

#### M-type plug connector (M)



Unless otherwise indicated, dimensions are the same as Grommet (G).

[ ] : AC

#### Dimensions



n: Stations (Max. 20 stations)

n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	85.5	85.5	98	110.5	123	135.5	148	148	160.5	173	185.5	198	210.5	210.5	223	235.5	248	260.5	273
L2	75	75	87.5	100	112.5	125	137.5	137.5	150	162.5	175	187.5	200	200	212.5	225	237.5	250	262.5
L3	43.5	54	64.5	75	85.5	96	106.5	117	127.5	138	148.5	159	169.5	180	190.5	201	211.5	222	232.5
L4	21	16	17	18	19	20	21	15.5	16.5	17.5	18.5	19.5	20.5	15.5	16.5	17.5	18.5	19.5	20.5
L5	30.5	41	51.5	62	72.5	83	93.5	104	114.5	125	135.5	146	156.5	167	177.5	188	198.5	209	219.5

## Dimensions: VQZ200


### VV3QZ22- [Stations] C

#### Grommet (G)




The dashed lines indicate the DIN rail mounting [-D].

#### L-type plug connector (L)




Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ] : AC

#### M-type plug connector (M)



Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ] : AC

#### DIN terminal (Y)



Unless otherwise indicated, dimensions are the same as Grommet (G).

#### Dimensions

n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	85.5	110.5	123	135.5	148	173	185.5	198	223	235.5	248	260.5	285.5	298	310.5	335.5	348	360.5	373
L2	75	100	112.5	125	137.5	162.5	175	187.5	212.5	225	237.5	250	275	287.5	300	325	337.5	350	362.5
L3	54	70	86	102	118	134	150	166	182	198	214	230	246	262	278	294	310	326	342
L4	16	20.5	18.5	17	15	19.5	18	16	20.5	19	17	15.5	20	18	16.5	21	19	17.5	15.5
L5	43	59	75	91	107	123	139	155	171	187	203	219	235	251	267	283	299	315	331

n: Stations (Max. 20 stations)





## Manifold Options


### Blanking plate assembly

**VVQZ100-10A-5 (for VQZ100)**

**VVQZ200-10A-2 (for VQZ200)**

**VVQZ300-10A-2 (for VQZ300)**

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.



### Blanking plug



**KQ2P-23**

**KQ2P-04**

**KQ2P-06**

**KQ2P-08**

**KQ2P-10**



#### Dimensions


Applicable fitting size $\phi d$	Model	A	L	D
3.2	<b>KQ2P-23</b>	16	31.5	5
4	<b>KQ2P-04</b>	16	32	6
6	<b>KQ2P-06</b>	18	35	8
8	<b>KQ2P-08</b>	20.5	39	10
10	<b>KQ2P-10</b>	22	43	12

### DIN rail

**AXT100-DR-□**

\* As for □, enter the number from the DIN rail dimensions table.  
For L dimension, refer to the dimensions of each kit.

Each manifold can be mounted on a DIN rail.  
Insert "D" at the end of the manifold part number.  
The DIN rail is approximately 30 mm longer than the length of manifold.





#### L Dimension

No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5
No.	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
L dimension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5

### Silencer

(for manifold EXH port)

Silencer is installed in the manifold EXH port.



#### Dimensions

Model	Silencer part no.
<b>VQZ100</b>	AN110-01
<b>VQZ200</b>	AN110-01
<b>VQZ300</b>	AN20-02

For a silencer to be mounted in a single valve unit, refer to page 1258.

**SYJ**

**VQZ**

**VP**

**VG**

**VP3**


# Semi-standard Specifications




## External Pilot Specification

The external pilot specification is used when the operating pressure is below the minimum operating pressure 0.1 to 0.15 MPa or when valve is used for a vacuum application. Order a valve by adding the external pilot specification [R] to the part number.

Valve Part No.



• Entry is the same as standard products.



## Pressure Specifications

Series		VQZ100 <sup>Note 2)</sup>	VQZ200/300
External pilot pressure range	<sup>Note 1)</sup> Metal seal	—	0.1 to 0.7 MPa
	Rubber seal (VQZ100: poppet)	0.2 to 0.7 MPa	0.15 to 0.7 MPa
Operating pressure range <sup>Note 1)</sup>		-100 kPa to 0.7 MPa	

Note 1) In case of the high pressure type, upper limit of max. operating pressure and external pilot pressure range is 1 MPa.


Note 2) Pump down from 3(P) port when VQZ100 series vacuum type is specified. Apply pressure from 3(R) port to relieve vacuum pressure. Set the release pressure at 50% of external pilot pressure or less.

In addition, when the VQZ100 is to be used at an operating pressure greater than 0.2 MPa, please assure that the operating pressure is set equal to or less than the external pilot pressure.

## Inch Size One-touch Fittings and Optional Threads

Inch size One-touch fittings and NPT, NPTF and G thread are available.

Valve Part No.



• Entry is the same as standard products.

Cylinder port •

• Thread type (Cylinder port and 1(P), 3(R) ports)

Symbol	N1	N3	N7	N9	N11	M5	O2
Applicable tubing O.D. (Inch)	ø1/8"	ø5/32"	ø1/4"	ø5/16"	ø3/8"	M5 thread	1/4 thread
2(A) port	VQZ100	●	●	●	—	●	—
	VQZ200	—	●	●	—	●	—
	VQZ300	—	—	●	●	—	●


Nil	Rc
N	NPT
T	NPTF
F	G

Note) Metric size One-touch fittings (C□) are also available.

Note 1) 3(R) port of the VQZ200 is only G1/16.

Note 2) Except VQZ100

Manifold Part No.



• Entry is the same as standard products.

• Thread type (1(P), 3(R) ports)


Nil	Rc
00N	NPT
00T	NPTF
00F	G

## IP65 Enclosure (Based on IEC60529)

DIN terminal is available with IP65 enclosure.

Valve Part No.

(Applicable to the VQZ200/300 rubber seal with the exception of the external pilot type)



• Entry is the same as standard products.

Note) The pilot exhaust IP65 valves is common with main valve exhaust. (The standard valve has an individual exhaust for the pilot valve.)

# VQZ Series Body Ported

## Replacement Parts

### One-touch Fitting Assembly (for Cylinder port)

Fitting size	C3	C4	C6	C8	C10	M5 (VQZ100 only)
Model	C3	C4	C6	C8	C10	M5 (VQZ100 only)
<b>VQZ100/200</b>	VVQ1000-50A-C3	VVQ1000-50A-C4	VVQ1000-50A-C6	—	—	VVQ1000-50A-M5
<b>VQZ300</b>	—	—	VVQ1000-51A-C6	VVQ1000-51A-C8	VVQ1000-51A-C10	—

Note) Purchasing order is available in units of 10 pieces.

#### <Plug connector assembly>

DC: SY100-30-4A-□

100 VAC: SY100-30-1A-□

200 VAC: SY100-30-2A-□

Other AC voltages: SY100-30-3A-□

Without lead wire: SY100-30-A  
(with connector and 2 sockets only)

#### Lead wire length

Nil	300 mm
6	600 mm
10	1000 mm
15	1500 mm
20	2000 mm
25	2500 mm
30	3000 mm
50	5000 mm

#### How to Order

Include the connector assembly part number together with the part number for the plug connector's solenoid valve without connector.

Example) In case of 2000 mm of lead wire

DC	AC
VQZ115-5L01-M5-PR	VQZ115-1L01-M5-PR
SY100-30-4A-20	SY100-30-1A-20

#### <Gasket and screw assembly>

Model	Part no.
<b>VQZ100</b>	VQZ100-GS-5
<b>VQZ200</b>	VQZ200-GS-2
<b>VQZ300</b>	VQZ300-GS-2

Note 1) The above part numbers are for 10 valves (a set of 10 gaskets and 20 screws).


Note 2) VQZ100 is common to the body ported type and base mounted type.

#### <Bracket assembly>

Model	Part no.	Tightening torque (N·m) <sup>Note1)</sup>
<b>VQZ100</b>	VQZ100-FB	0.25 to 0.35
<b>VQZ200</b>	VQZ200-FB	
<b>VQZ300</b>	VQZ300-FB	

Note) Tightening torque when mounting a bracket on the valve.

#### <Pilot valve assembly>



#### Electrical entry

Symbol	DC	AC	Electrical entry	Light/surge voltage suppressor
<b>G</b>	—	—	Grommet (DC specification)	None
<b>LU</b>	<b>LZ</b>	—	L-type plug connector with lead wire	Yes
<b>LOU</b>	<b>LOZ</b>	—	L-type plug connector without connector	
<b>MU</b>	<b>MZ</b>	—	M-type plug connector with lead wire	
<b>MOU</b>	<b>MOZ</b>	—	M-type plug connector without connector	

Note) VQZ pilot valve electrical entry (L, M) is the opposite of the how to order of valve body.

Valve model	Pilot valve model
VQZ115□-□L□1	V111□M-□M□
VQZ115□-□M□1	V111□M-□L□

#### <DIN terminal type (Applicable to the VQZ200/300)>



**Function**

Symbol	Specifications	DC	AC
Nil	Standard	(0.35 W) ○	○
<b>B</b> <sup>Note)</sup>	High speed response type	(0.9 W) ○	—
<b>K</b> <sup>Note)</sup>	High pressure type (Metal seal type only)	(0.9 W) ○	—

Note) Semi-standard

#### Coil voltage

1	100 VAC (50/60 Hz)
2	200 VAC (50/60 Hz)
3	110 VAC [115 VAC] (50/60 Hz)
4	220 VAC [230 VAC] (50/60 Hz)
5	24 VDC
6	12 VDC

#### Electrical entry

Symbol	DC	AC	Electrical entry	Light/surge voltage suppressor
<b>Y</b>	—	—	DIN terminal	None
<b>YO</b>	—	—	DIN terminal without connector	
<b>YZ</b>	—	—	DIN terminal with light/surge voltage suppressor	Yes
<b>YS</b> <sup>Note)</sup>	—	—	DIN terminal with surge voltage suppressor (DC specification)	Yes
<b>YOS</b> <sup>Note)</sup>	—	—	DIN terminal with surge voltage suppressor, without connector (DC specification)	(Without light)

Note) For AC voltage valves there is no "S" type. It is already built-in to the rectifier circuit.

### ⚠ Caution

When replacing only the pilot valve assembly, use caution because it is not possible to convert to a V115 (DIN terminal) from a V111 (Grommet, L-type, M-type), or vice versa.

Base Mounted  
Plug Lead Unit

# 3 Port Solenoid Valve

## VQZ100/200/300 Series

### Single Unit




[Option]  
Note) For CE-compliant models, DC type only.

### VQZ100 / How to Order Valve

VQZ 1 1 5 [ ] - 5 M [ ] 1 - 01 - [ ]

Series ●  
1 VQZ100 body width 10 mm

Type of actuation ●



Body type ●

5 Base mounted

Function ●

Symbol	Specifications	DC	AC
Nil	Standard	○ (0.35 W) Note 3)	○
K Note 1)	High pressure type	○ (0.9 W)	—
R Note 1, 2)	External pilot type	○	○
KR Note 1, 2)	High pressure/External pilot type	○ (0.9 W)	—

Note 1) Semi-standard  
Note 2) For details on external pilot type, refer to page 1253.  
Note 3) For AC specification power consumption, refer to page 1240.

**Caution**  
Use standard (DC) specification for continuous duty.

CE-compliant

Nil	—
Q	CE-compliant


Note) For CE-compliant models, DC type only.

Port size

CP	Without sub-plate
01	Rc 1/8

Note) For optional thread type, refer to page 1253.

Manual override



Electrical entry

G: Grommet (DC specification)	L: L-type plug connector with lead wire	LO: L-type plug connector without connector	M: M-type plug connector with lead wire	MO: M-type plug connector without connector
	With light/surge voltage suppressor	With light/surge voltage suppressor	With light/surge voltage suppressor	With light/surge voltage suppressor

Note) Standard lead wire length: 300 mm

Coil voltage

	CE-compliant
1 100 VAC (50/60 Hz)	—
2 200 VAC (50/60 Hz)	—
3 110 VAC [115 VAC] (50/60 Hz)	—
4 220 VAC [230 VAC] (50/60 Hz)	—
5 24 VDC	●
6 12 VDC	●

Note) For sub-plate part no., refer to page 1254.  
Note) When ordering single unit of the base mounted type solenoid valve, the mounting screws and gaskets for the manifold are included.

## VQZ200/300 / How to Order Valve



**Made to Order**  
 (For details, refer to pages 1240 and 1255.)

Note) AC-type models that are CE-compliant have DIN terminals only.



**VQZ 2 1 5** - **5 M** - **1** -

**Series**

2	VQZ200 body width 15 mm
3	VQZ300 body width 18 mm

**Type of actuation**

1	N.C.	2(A)	Metal seal
	(R)S	1(P)	
2	N.O.	2(A)	Metal seal
	(R)S	1(P)	
3	N.C.	2(A)	Rubber seal
	(R)S	1(P)	
4	N.O.	2(A)	Rubber seal
	(R)S	1(P)	

**Body type**

5	Body mounted
---	--------------

**Function**

Symbol	Specifications	DC	AC
<b>Nil</b>	Standard	(0.35 W) <small>Note 3)</small>	—
<b>B</b> <small>Note 1)</small>	High speed response type	(0.9 W)	—
<b>K</b> <small>Note 1)</small>	High pressure type (Metal seal type only)	(0.9 W)	—
<b>R</b> <small>Note 1, 2)</small>	External pilot type	—	—
<b>BR</b> <small>Note 1, 2)</small>	High speed response/External pilot type	(0.9 W)	—
<b>KR</b> <small>Note 1, 2)</small>	High pressure/External pilot type (Metal seal type only)	(0.9 W)	—

Note 1) Semi-standard  
 Note 2) For details on external pilot type, refer to page 1253.  
 Note 3) For AC specification power consumption, refer to page 1240.

**Caution**  
 Use standard (DC) specification for continuous duty.

**IP65 compliant**

<b>Nil</b>	—
<b>W</b> <small>Note)</small>	Compliant

Note) VQZ200/300 DIN terminal rubber seal only (except external pilot). For details on IP65 enclosure, refer to page 1253.

**CE-compliant**

<b>Nil</b>	—
<b>Q</b>	CE-compliant

Note) AC-type models that are CE-compliant have DIN terminals only.

**Port size**

Symbol	Port size	VQZ200	VQZ300
<b>Nil</b>	Without sub-plate	○	○
<b>01</b>	Rc 1/8	○	—
<b>02</b>	Rc 1/4	○	○
<b>03</b>	Rc 3/8	—	○

Note) For optional thread type, refer to page 1253.

**Manual override**

<b>Nil</b> : Non-locking push type (Tool required)	<b>B</b> : Locking type (Tool required)

**Electrical entry**

	<b>G</b> : Grommet (DC specification)	<b>L</b> : L-type plug connector with lead wire	<b>LO</b> : L-type plug connector without connector	<b>M</b> : M-type plug connector with lead wire	<b>MO</b> : M-type plug connector without connector
<b>CE</b> <small>Note 1)</small>	—	—	—	—	—
<b>AC</b>	—	—	—	—	—
<b>DC</b>	—	—	—	—	—
<b>Y</b> : DIN terminal	<b>YO</b> : DIN terminal without connector	<b>YZ</b> : DIN terminal	<b>YOS</b> : DIN terminal without connector (DC specification)	<b>YS</b> : DIN terminal (DC specification)	<b>YS</b> : DIN terminal (DC specification)
<b>CE</b> <small>Note 1)</small>	—	—	—	—	—
<b>AC</b>	●	●	●	—	—
<b>DC</b>	●	●	●	●	●

Note 1) Standard lead wire length: 300 mm

Note 2) For AC voltage valves there is no "S" type. It is already built-in to the rectifier circuit.

**Coil voltage**

1	100 VAC (50/60 Hz)
2	200 VAC (50/60 Hz)
3	110 VAC [115 VAC] (50/60 Hz)
4	220 VAC [230 VAC] (50/60 Hz)
5	24 VDC
6	12 VDC

Note) For sub-plate part no., refer to page 1254.  
 Note) When ordering single unit of the base mounted type solenoid valve, the mounting screws and gaskets for the manifold are included.



**SYJ**  
**VQZ**  
**VP**  
**VG**  
**VP3**



## Construction

### VQZ100

Poppet type





### Component Parts







No.	Description	Material	Note
1	Body	Resin	
2	Spool valve	Aluminum/HNBR	
3	Pilot valve assembly	—	
4	Port plug	Resin/HNBR	VQZ100-CP

### VQZ200/300

Metal seal type



Rubber seal type



### Component Parts

No.	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool, Sleeve	Stainless steel	Metal seal
2	Spool valve	Aluminum/HNBR	Rubber seal
3	Piston	Resin	
4	Pilot valve assembly	—	

Note) For "How to Order Pilot Valve Assembly", refer to page 1254.

SYJ

VQZ

VP

VG


VP3

# VQZ100/200/300 Series


## Dimensions: VQZ100

### Single Unit


Grommet (G): VQZ115□-□G□1-01



### L-type plug connector (L): VQZ115□-□L□1-01



### M-type plug connector (M): VQZ115□-□M□1-01



Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ]: AC


Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ]: AC



## Dimensions: VQZ200


### Single Unit

Grommet (G): VQZ2□5□-□G□1-<sup>01</sup>/<sub>02</sub>




( ): VQZ215-□G□1-01

L-type plug connector (L): VQZ2□5□-□L□1-<sup>01</sup>/<sub>02</sub>




Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ] : AC

M-type plug connector (M): VQZ2□5□-□M□1-<sup>01</sup>/<sub>02</sub>



Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ] : AC

DIN terminal (Y): VQZ2□5□-□Y□□1-<sup>01</sup>/<sub>02</sub>



Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ] : AC

SYJ

VQZ

VP

VG


VP3

# VQZ100/200/300 Series

## Dimensions: VQZ300


### Single Unit

Grommet (G): VQZ3□5□-□G□1-02/03




( ) : VQZ315-□G□1-02

L-type plug connector (L): VQZ3□5□-□L□1-02/03




Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ] : AC

M-type plug connector (M): VQZ3□5□-□M□1-02/03



Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ] : AC

DIN terminal (Y): VQZ3□5□-□Y□□1-02/03



Unless otherwise indicated, dimensions are the same as Grommet (G).

Base Mounted  
Plug Lead Unit

# 3 Port Solenoid Valve

## VQZ100/200/300 Series

### Manifold Connector Kit



[Option]  
Note) For CE-compliant models, DC-type only.

#### VQZ100 / How to Order Manifold

**VV3QZ 1 5 - 08 C6 C -**

**Series**  
1 VQZ100

**Manifold type**  
5 Base mounted

**Stations**

02	2 stations
⋮	⋮
20	20 stations

**Port size [2(A) port]**

C3	ø3.2 One-touch fitting	For side ported
C4	ø4 One-touch fitting	
C6	ø6 One-touch fitting	
M5	M5 thread (Replaceable type)	For top ported
CP <sup>Note 1)</sup>	With port plug	
CM <sup>Note 2)</sup>	Mixed port sizes	

**CE-compliant**

Nil	—
Q	CE-compliant

**Option**

Nil	None
D	DIN rail mounting (With standard DIN rail length)
DO <sup>Note)</sup>	DIN rail mounting (Without DIN rail)
R	External pilot type

Note 1) Order DIN rail separately.  
For DIN rail part no., refer to page 1252.  
Note 2) When two or more symbols are specified, indicate them alphabetically.

**Kit type**  
C Connector

Note 1) When CP port plug is attached on all 2(A) port. Valve on manifold is top ported.  
Note 2) Specify the mixture port (including top and side piping) by the manifold specification sheet.  
Note 3) For inch size One-touch fittings, refer to page 1253.

#### VQZ100 / How to Order Valve

**VQZ 1 1 5 - 5 M 1 - C4 -**

**Series**  
1 VQZ100 body width 10 mm

**Type of actuation**  
1 N.C.

**Body type**  
5 Base mounted

**Function**

Symbol	Specifications	DC	AC
Nil	Standard	(0.35 W) ○	Note 3) ○
K <sup>Note 1)</sup>	High pressure type	(0.9 W) ○	—
R <sup>Note 1, 2)</sup>	External pilot type	○	○
KR <sup>Note 1, 2)</sup>	High pressure/External pilot type	(0.9 W) ○	—

**CE-compliant**

Nil	—
Q	CE-compliant

Note) For CE-compliant models, DC type only.

**Port size**

CP	With port plug	For side ported
C3	ø3.2 One-touch fitting	For top ported
C4	ø4 One-touch fitting	
C6	ø6 One-touch fitting	
M5	M5 thread	

Note) For inch size One-touch fittings, refer to page 1253.

**Manual override**

Nil	Non-locking push type (Tool required)
B	Locking type (Tool required)

**Coil voltage**

		CE-compliant
1	100 VAC (50/60 Hz)	—
2	200 VAC (50/60 Hz)	—
3	110 VAC [115 VAC] (50/60 Hz)	—
4	220 VAC [230 VAC] (50/60 Hz)	—
5	24 VDC	●
6	12 VDC	●

**Electrical entry**

Symbol	Electrical entry	Light/surge voltage suppressor
G	Grommet (DC specification)	None
L	L-plug plug connector with lead wire	Yes
LO	L-plug plug connector without connector	
M	M-plug plug connector with lead wire	
MO	M-plug plug connector without connector	

Note) Standard lead wire length: 300 mm  
Note) When ordering single unit of the base mounted type solenoid valve, the mounting screws and gaskets for the manifold are included.

**Caution**  
Use standard (DC) specification for continuous duty.

SYJ  
VQZ  
VP  
VG  
VP3

# VQZ100/200/300 Series

## VQZ200/300 / How to Order Manifold



**Made to Order**  
(For details, refer to page 1255.)

Note) AC-type models that are CE-compliant have DIN terminals only. [Option]



**VV3QZ 2 5 - 08 C6 C - - -**

**Series**

2	VQZ200
3	VQZ300

**Manifold type**

5	Base mounted
---	--------------

**Stations**

02	2 stations
:	:
20	20 stations

**Port size [2(A) port]**

Symbol	Port size	VQZ200	VQZ300
C4	ø4 One-touch fitting	○	—
C6	ø6 One-touch fitting	○	○
C8	ø8 One-touch fitting	○	○
C10	ø10 One-touch fitting	—	○
01	Rc 1/8	○	—
02	Rc 1/4	—	○
CM	Mixed port sizes	○	○

Note 1) Specify port mixture/with port plug by means of the manifold specification sheet. Port mixture and port plug are available only for one-touch fitting type.  
Note 2) For inch size One-touch fittings, refer to page 1253.

**CE-compliant**

Nil	—
Q	CE-compliant

**Option**

Nil	None
D	DIN rail mounting (With standard DIN rail length)
DO	DIN rail mounting (Without DIN rail)
R	External pilot type

Note 1) Order DIN rail separately.  
For DIN rail part no., refer to page 1252.  
Note 2) When two or more symbols are specified, indicate them alphabetically.

**Kit type**

C	Connector
---	-----------

## VQZ200/300 / How to Order Valve

**VQZ 2 1 5 - 5 M - - 1 -**

**Series**

2	VQZ200 body width 15 mm
3	VQZ300 body width 18 mm

**Type of actuation**

1	N.C. Metal seal
2	N.O. Metal seal
3	N.C. Rubber seal
4	N.O. Rubber seal

**Body type**

5	Base mounted
---	--------------

**Function**

Symbol	Specifications	DC	AC
Nil	Standard	(0.35 W) Note 3) ○	○
B	High speed response type	(0.9 W) ○	—
K	High pressure type (Metal seal type only)	(0.9 W) ○	—
R	External pilot type	○	○
BR	High speed response/External pilot type	(0.9 W) ○	○
KR	High pressure/External pilot type (Metal seal type only)	(0.9 W) ○	—

Note 1) Semi-standard  
Note 2) For details on external pilot type, refer to page 1253.  
Note 3) For AC specification power consumption, refer to page 1240.

**CE-compliant**

Nil	—
Q	CE-compliant

Note) AC-type models that are CE-compliant have DIN terminals only.

**IP65 compliant**

Nil	—
W	Compliant

Note) VQZ200/300 DIN terminal rubber seal only (except external pilot). For details on IP65 enclosure, refer to page 1253.

**Manual override**

Nil	Non-locking push type (Tool required)
B	Locking type (Tool required)

**Electrical entry**

Symbol	Electrical entry	Light/surge voltage suppressor	CE-compliant AC	DC
G	Grommet (DC specification)	None	—	●
L	L-type plug connector with lead wire	Yes	—	●
LO	L-type plug connector without connector		—	●
M	M-type plug connector with lead wire		—	●
MO	M-type plug connector without connector		—	●
Y	DIN terminal	None	●	●
YO	DIN terminal without connector		●	●
YZ	DIN terminal		●	●
YS	DIN terminal (DC specification)	Yes	—	●
YOS	DIN terminal without connector (DC specification)	Yes (Without light)	—	●

Note 1) Standard lead wire length: 300 mm  
Note 2) For AC voltage valves there is no "S" type. It is already built-in to the rectifier circuit.

**Coil voltage**


1	100 VAC (50/60 Hz)
2	200 VAC (50/60 Hz)
3	110 VAC [115 VAC] (50/60 Hz)
4	220 VAC [230 VAC] (50/60 Hz)
5	24 VDC
6	12 VDC



**Caution**  
Use standard (DC) specification for continuous duty.

Note) When ordering single unit of the base mounted type solenoid valve, the mounting screws and gaskets for the manifold are included.


## Manifold Specifications



Series	Base model	Piping specifications			Applicable solenoid valve	Applicable stations	Manifold base weight (g) <sup>Note)</sup>
		Piping direction	Port size				
			1(P), 3(R)	2(A)			
VQZ100	VV3QZ15-□□□	Side/Top	Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ115	2 to 20 stations	2 stations: 83 Addition per station: 19
VQZ200	VV3QZ25-□□□	Side	Rc 1/4	C4 (for ø4) C6 (for ø6) C8 (for ø8) Rc 1/8	VQZ2□5	2 to 20 stations	2 stations: 126 Addition per station: 38
VQZ300	VV3QZ35-□□□	Side	1(P) port Rc 3/8 3(R) port Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3□5	2 to 20 stations	2 stations: 209 Addition per station: 60

Note) Weight for threaded connection.

## How to Order Manifold Assembly (Example)



VV3QZ25-05C6C ..... 1 set (C kit 5-station manifold base part no.)  
 VVQZ200-10A-5 ..... 1 set (Blanking plate assembly part no.)  
 VQZ215-5L1 ..... 4 sets (N.C. type part no.)

→ The asterisk denotes the symbol for assembly. Prefix it to the part nos. of the solenoid valve, etc.  
 → Enter in order starting from the first station on the D side.

Add the valve and option part number under the manifold base part number.  
 When entry of part numbers becomes complicated, indicate by the manifold specification sheet.


- SYJ
- VQZ
- VP
- VG
- VP3

# VQZ100/200/300 Series

## Dimensions: VQZ100: Top Ported


VV3QZ15- Stations | Port size C

### Grommet (G)



The dashed lines indicate the DIN rail mounting [-D].

### M5




### Dimensions

n: Stations (Max. 20 stations)


n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
<b>L1</b>	85.5	85.5	98	110.5	123	135.5	148	148	160.5	173	185.5	198	210.5	210.5	223	235.5	248	260.5	273
<b>L2</b>	75	75	87.5	100	112.5	125	137.5	137.5	150	162.5	175	187.5	200	200	212.5	225	237.5	250	262.5
<b>L3</b>	43.5	54	64.5	75	85.5	96	106.5	117	127.5	138	148.5	159	169.5	180	190.5	201	211.5	222	232.5
<b>L4</b>	21	16	17	18	19	20	21	15.5	16.5	17.5	18.5	19.5	20.5	15.5	16.5	17.5	18.5	19.5	20.5
<b>L5</b>	30.5	41	51.5	62	72.5	83	93.5	104	114.5	125	135.5	146	156.5	167	177.5	188	198.5	209	219.5

## Dimensions: VQZ100: Side Ported

VV3QZ15- Stations Port size C




### L-type plug connector (L)



Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ]: AC

### M-type plug connector (M)



Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ]: AC

### Dimensions

n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	85.5	85.5	98	110.5	123	135.5	148	148	160.5	173	185.5	198	210.5	210.5	223	235.5	248	260.5	273
L2	75	75	87.5	100	112.5	125	137.5	137.5	150	162.5	175	187.5	200	200	212.5	225	237.5	250	262.5
L3	43.5	54	64.5	75	85.5	96	106.5	117	127.5	138	148.5	159	169.5	180	190.5	201	211.5	222	232.5
L4	21	16	17	18	19	20	21	15.5	16.5	17.5	18.5	19.5	20.5	15.5	16.5	17.5	18.5	19.5	20.5
L5	30.5	41	51.5	62	72.5	83	93.5	104	114.5	125	135.5	146	156.5	167	177.5	188	198.5	209	219.5


n: Stations (Max. 20 stations)

# VQZ100/200/300 Series

## Dimensions: VQZ200

VV3QZ25- Stations Port size C


### Grommet (G)



(Station 1) ----- (Station n)


The dashed lines indicate the DIN rail mounting [-D].

### L-type plug connector (L)




Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ]: AC

### M-type plug connector (M)



Unless otherwise indicated, dimensions are the same as Grommet (G).  
[ ]: AC

### DIN terminal (Y)



Unless otherwise indicated, dimensions are the same as Grommet (G).

### Dimensions

n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	85.5	98	123	135.5	148	173	185.5	198	210.5	235.5	248	260.5	285.5	298	310.5	323	348	360.5	373
L2	75	87.5	112.5	125	137.5	162.5	175	187.5	200	225	237.5	250	275	287.5	300	312.5	337.5	350	362.5
L3	52	68	84	100	116	132	148	164	180	196	212	228	244	260	276	292	308	324	340
L4	17	15	19.5	18	16	20.5	19	17	15.5	20	18	16.5	21	19	17.5	15.5	20	18.5	16.5
L5	42	58	74	90	106	122	138	154	170	186	202	218	234	250	266	282	298	314	330

n: Stations (Max. 20 stations)





# VQZ100/200/300 Series

## Manifold Options


### Blanking plate assembly

VVQZ100-10A-5 (for VQZ100)

VVQZ200-10A-5 (for VQZ200)

VVQZ300-10A-5 (for VQZ300)

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.



### Blanking plug


KQ2P-23

KQ2P-04

KQ2P-06

KQ2P-08

KQ2P-10



#### Dimensions

		(mm)		
Applicable fitting size $\phi d$	Model	A	L	D
3.2	<b>KQ2P-23</b>	16	31.5	5
4	<b>KQ2P-04</b>	16	32	6
6	<b>KQ2P-06</b>	18	35	8
8	<b>KQ2P-08</b>	20.5	39	10
10	<b>KQ2P-10</b>	22	43	12

### DIN rail


AXT100-DR-□

\* As for □, enter the number from the DIN rail dimensions table. For L dimension, refer to the dimensions of each kit.

Each manifold can be mounted on a DIN rail.

Insert "D" at the end of the manifold part number.

The DIN rail is approximately 30 mm longer than the length of manifold.





#### L Dimension

No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5
No.	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
L dimension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5

### Silencer

(for manifold EXH port)

Silencer is installed in the manifold EXH port.



#### Dimensions

Model	Silencer part no.
<b>VQZ100</b>	AN110-01
<b>VQZ200</b>	AN20-02
<b>VQZ300</b>	AN20-02

### Port plug

VVQZ100-CP (for VQZ100)

This is used when changing piping location. (Side or Top)



# Semi-standard Specifications



## External Pilot Specification

The external pilot specification is used when the operating pressure is below the minimum operating pressure 0.1 to 0.15 MPa or when valve is used for a vacuum application. Order a valve by adding the external pilot specification [R] to the part number.


### Valve Part No.



• Entry is the same as standard products.

### CE-compliant

Nil	—
Q	CE-compliant



### Manifold Part No.



• Entry is the same as standard products.

## Pressure Specifications

Series		VQZ100 <small>Note 2)</small>	VQZ200/300
External pilot pressure range <small>Note 1)</small>	Metal seal	—	0.1 to 0.7 MPa
	Rubber seal (VQZ100: poppet)	0.2 to 0.7 MPa	0.15 to 0.7 MPa
Operating pressure range <small>Note 1)</small>		-100 kPa to 0.7 MPa	

Note 1) In case of the high pressure type, upper limit of max. operating pressure and external pilot pressure range is 1 MPa.

Note 2) When using the VQZ100 series for a vacuum application, vacuum air through its 1(P) port. When supplying vacuum-release air, supply it through its 3(R) port. But do not supply vacuum-release air exceeding 50% for the external pilot pressure.

In addition, when the VQZ100 is to be used at an operating pressure greater than 0.2 MPa, please assure that the operating pressure is set to equal to or less than the external pilot pressure.

## Inch Size One-touch Fittings and Optional Threads

Inch size One-touch fittings and NPT, NPTF and G thread are available.

### Manifold Part No.



• Entry is the same as standard products.

• Cylinder port

### CE-compliant

Nil	—
Q	CE-compliant

• Thread type (Cylinder port and 1(P), 3(R) ports)

Symbol	N1	N3	N7	N9	N11	NM <small>Note 1)</small>	M5	O1	O2
Applicable tubing O.D.	ø1/8"	ø5/32"	ø1/4"	ø5/16"	ø3/8"	Mixed	M5 thread	1/8 thread	1/4 thread
Cylinder port	VQZ100	●	●	●	—	—	●	—	—
	VQZ200	—	—	●	●	—	—	●	—
	VQZ300	—	—	—	●	●	—	—	●

Note 1) Except VQZ100, mixing One-touch fittings and thread types is impossible.

Note 2) Metric size One-touch fittings (C□) are also available.

Nil	Rc
N	NPT
T	NPTF
F	G

SYJ

VQZ

VP

VG

VP3

## Optional Threads Other than Rc

Rc specifications are standard for all ports, however, NPT, NPTF and G are available for overseas markets. Add the appropriate symbol following the port size in the standard part number.

### Valve Part No.



• Entry is the same as standard products.

### CE-compliant

Nil	—
Q	CE-compliant

• Thread type (Cylinder port and 1(P), 3(R) ports of sub-plate)

Nil	Rc
N	NPT
T	NPTF
F	G

## IP65 Enclosure (Based on IEC60529)

DIN terminal is available with IP65 enclosure.

### Valve Part No.

(Applicable to the VQZ200/300 rubber seal with the exception of the external pilot type)



• Entry is the same as standard products.

### CE-compliant

Nil	—
Q	CE-compliant

Note) The pilot exhaust IP65 valves is common with main valve exhaust. (The standard valve has an individual exhaust for the pilot valve.)

## Replacement Parts

### One-touch Fitting Assembly (for Cylinder port)

Fitting size	C3	C4	C6	C8	C10	M5 (VQZ100 only)
<b>VQZ100</b>	VVQ1000-50A-C3	VVQ1000-50A-C4	VVQ1000-50A-C6	—	—	VVQ1000-50A-M5
<b>VQZ200</b>	—	VVQ1000-51A-C4	VVQ1000-51A-C6	VVQ1000-51A-C8	—	—
<b>VQZ300</b>	—	—	VVQ2000-51A-C6	VVQ2000-51A-C8	VVQ2000-51A-C10	—

Note) Purchasing order is available in units of 10 pieces.

#### <Plug connector assembly>

- DC: SY100-30-4A-□
- 100 VAC: SY100-30-1A-□
- 200 VAC: SY100-30-2A-□
- Other AC voltages: SY100-30-3A-□

Without lead wire: SY100-30-A  
(with connector and 2 sockets only)

#### Lead wire length

Nil	300 mm
6	600 mm
10	1000 mm
15	1500 mm
20	2000 mm
25	2500 mm
30	3000 mm
50	5000 mm

#### How to Order

Include the connector assembly part number together with the part number for the plug connector's solenoid valve without connector.

Example) In case of 2000 mm of lead wire

<b>DC</b>	<b>AC</b>
VQZ115-5LO1-M5	VQZ115-1LO1-M5
SY100-30-4A-20	SY100-30-1A-20

#### <Gasket and screw assembly>

Model	Part no.
<b>VQZ100</b>	VQZ100-GS-5
<b>VQZ200</b>	VQZ200-GS-5
<b>VQZ300</b>	VQZ300-GS-5

Note) The above part numbers are for 10 valves (a set of 10 gaskets and 20 screws).



#### <Sub-plate>

Model	Sub-plate part no.	
	For internal pilot	For external pilot
<b>VQZ100</b>	VQZ100-S-01□ (-Q)	VQZ100-S-01□ (-R (-Q))
<b>VQZ200</b>	VQZ200-S-01□ (-Q)	VQZ200-S-01□ (-R (-Q))
<b>VQZ300</b>	VQZ300-S-02□ (-Q)	VQZ300-S-02□ (-R (-Q))

\* Thread type

#### <Pilot valve assembly>

V111 □ □ — 5 G □ □

Symbol	Specifications	DC	AC
<b>Nil</b>	Standard	(0.35 W) <input type="radio"/>	<input type="radio"/>
<b>B</b> <small>Note)</small>	High speed response type (Applicable to VQZ200/300)	(0.9 W) <input type="radio"/>	—
<b>K</b> <small>Note)</small>	High pressure type (Applicable to Metal seal type, Poppet seal type)	(0.9 W) <input type="radio"/>	—

Note) Semi-standard

#### Function

#### Manual override

<b>Nil</b>	None (Applicable to VQZ200/300)
<b>M</b>	Yes (Applicable to VQZ100)

#### Manual override (Applicable to the VQZ100)

<b>Nil</b>	Non-locking push type
<b>B</b>	Locking slotted type

#### Coil voltage

1	100 VAC (50/60 Hz)
2	200 VAC (50/60 Hz)
3	110 VAC (115 VAC) (50/60 Hz)
4	220 VAC (230 VAC) (50/60 Hz)
5	24 VDC
6	12 VDC

#### Electrical entry

Symbol	DC	AC	Electrical entry	Light/surge voltage suppressor
<b>G</b>	—	—	Grommet (DC specification)	None
<b>LU LZ</b>	—	—	L-type plug connector with lead wire	Yes
<b>LOU LOZ</b>	—	—	L-type plug connector without connector	
<b>MU MZ</b>	—	—	M-type plug connector with lead wire	
<b>MOU MOZ</b>	—	—	M-type plug connector without connector	

Note) The electrical entry (L, M) for the VQZ100 pilot valve is different from that of the main valve model number.

Valve model	Pilot valve model
VQZ115□□□L01	V111□M□□□
VQZ115□□□M01	V111□M□□□

#### <DIN terminal type (Applicable to the VQZ200/300)>

V115 □ □ — 5 Y — X110

Symbol	Specifications	DC	AC
<b>Nil</b>	Standard	(0.35 W) <input type="radio"/>	<input type="radio"/>
<b>B</b> <small>Note)</small>	High speed response type	(0.9 W) <input type="radio"/>	—
<b>K</b> <small>Note)</small>	High pressure type (Metal seal type only)	(0.9 W) <input type="radio"/>	—

Note) Semi-standard

#### Coil voltage

1	100 VAC (50/60 Hz)
2	200 VAC (50/60 Hz)
3	110 VAC (115 VAC) (50/60 Hz)
4	220 VAC (230 VAC) (50/60 Hz)
5	24 VDC
6	12 VDC

#### Electrical entry

Symbol	DC	AC	Electrical entry	Light/surge voltage suppressor
<b>Y</b>	—	—	DIN terminal	None
<b>YO</b>	—	—	DIN terminal without connector	
<b>YZ</b>	—	—	DIN terminal with light/surge voltage suppressor	Yes
<b>YS</b> <small>Note)</small>	—	—	DIN terminal with surge voltage suppressor (DC specification)	Yes
<b>YOS</b> <small>Note)</small>	—	—	DIN terminal with surge voltage suppressor, without connector (DC specification)	(Without light)

Note) For AC voltage valves there is no "S" option. It is already built-in to the rectifier circuit.

### ⚠ Caution

When replacing only the pilot valve assembly, use caution because it is not possible to convert to a V115 (DIN terminal) from a V111 (Grommet, L-type, M-type), or vice versa.

# VQZ200/300 Series

## Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.




### 1 Pilot Valve Common Exhaust Specification

Pilot exhaust is exhausted through the main R port.

- \* Not designed to prevent leakage to outside.
- \* A combination of external pilots is not available.
- \* "How to Order Manifold" is the same as standard products. Please specify this to "How to Order Valve."

Applicable solenoid valve series: VQZ200/300

#### How to Order




### 2 Main Valve Fluororubber Specification

The seal material, the part of the main valve in contact with fluid, is made of fluororubber.

- \* "How to Order Manifold" is the same as standard products. Please specify this to "How to Order Valve."

Applicable solenoid valve series: VQZ200/300

#### How to Order



- SYJ
- VQZ
- VP
- VG
- VP3


### 3 All Fluororubber Specification

The rubber material of the part in contact with fluid, is made of fluororubber.

- \* "How to Order Manifold" is the same as standard products. Please specify this to "How to Order Valve."

Applicable solenoid valve series: VQZ200/300

#### How to Order





# VQZ Series

## Specific Product Precautions 1

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 3 to 9 for 3/4/5 Port Solenoid Valve Precautions.


### Manual Override

#### ⚠ Caution

Without an electric signal for the solenoid valve the manual override is used for switching the main valve. Push type is standard. Locking type (Tool required) is available as an option.


##### 1. VQZ100

Push type



Press in the direction of the arrow.


Locking type (Tool required)



Turn 90° in the direction of arrow.


##### 2. VQZ200/300

Push type (Tool required)




Push down on the manual override button with a small screwdriver until it stops. Release the screwdriver and the manual override will return.

Locking type (Tool required)



Push down completely on the manual override button with a small screwdriver. While down, turn clockwise 90° to lock it. Turn it counterclockwise to release it.

Locked position



#### Precautions


When operating with a screwdriver, turn it gently using a watchmaker's screwdriver. (Torque: less than 0.1 N·m)  
Press and rotate to lock the manual operation of VQZ200/300. If rotate without pressing, manual breakage and air leakage could be occurred.

### How to Use L/M-Type Plug Connector

#### ⚠ Caution

##### 1. Attaching and detaching connectors

To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve and remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.




### Light/Surge Voltage Suppressor


#### ⚠ Caution

##### 1. L/M-type plug connector

<DC>




<AC>




##### 2. DIN terminal

<DC>

With surge voltage suppressor (YS, YOS)




Light/surge voltage suppressor (YZ)



<AC>

With light (YZ)



Note) Surge voltage suppressor of varistor has residual voltage corresponding to the protective element and rated voltage; therefore, protect the controller side from the surge.



# VQZ Series

## Specific Product Precautions 2

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 3 to 9 for 3/4/5 Port Solenoid Valve Precautions.


### Lead Wire Connection

#### ⚠ Caution

##### 1. Crimping of lead wires and sockets

Not necessary if ordering the lead wire pre-connected model. Strip 3.2 to 3.7 mm at the end of the lead wires, insert the ends of the core wires evenly into the sockets, and then crimp with a crimping tool. When this is done, take care that the coverings of the lead wires do not enter the core wire crimping area.

(Please contact SMC for the crimping tools.)




##### 2. Attaching and detaching sockets with lead wires

###### Attaching

Insert the sockets into the square holes of the connector (⊕, ⊖ indication), and continue to push the sockets all the way in until they lock by hooking into the seats in the connector. (When they are pushed in, their hooks open and they are locked automatically.) Then, confirm that they are locked by pulling lightly on the lead wires.

###### Detaching

To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (approx. 1 mm). If the socket will be used again, first spread the hook outward.




### Pilot Valve Replacement

#### ⚠ Caution


1. When replacing a current type valve with a new type for maintenance or other reasons, a "conversion connector assembly" is necessary to convert the connector from 3 terminals to 2 terminals and must be ordered separately. (When ordering, refer to the below part nos.)

For pilot valves, there is no compatibility between the current type and new type. When replacing a pilot valve, be sure to confirm whether it is the new type or the current type.

[Current]



[New]



SYJ

VQZ

VP

VG

VP3



# VQZ Series

## Specific Product Precautions 3

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 3 to 9 for 3/4/5 Port Solenoid Valve Precautions.

### How to Use DIN Terminal

#### 1. EN-175301-803C (Former DIN 43650C) (8 mm between pins)

The DIN terminal type with an IP65 enclosure is protected against dust and water, however, it must not be used in water.

#### 2. Connection

- Loosen the holding screw and pull the connector out of the solenoid valve terminal block.
- After removing the holding screw, insert a flat head screwdriver, etc. into the notch on the bottom of the terminal block and pry it open, separating the terminal block and the housing.
- Loosen the terminal screws (slotted screws) on the terminal block, insert the cores of the lead wires into the terminals according to the connection method, and fasten them securely with the terminal screws.
- Secure the cord by fastening the ground nut.

#### 3. Changing the entry direction

After separating the terminal block and housing, the cord entry can be changed by attaching the housing in the desired direction (4 directions at 90° intervals).


\* When equipped with a light, be careful not to damage the light with the cord's lead wires.

#### 4. Precautions

Plug in and pull out the connector vertically without tilting to one side.

#### 5. Compatible cable

Cable O.D.:  $\phi 3.5$  to  $\phi 7$   
(Reference) 0.5 mm<sup>2</sup>, 2-core or 3-core, equivalent to JIS C 3306



### DIN Connector Part No.


#### Without light

Rated voltage	Voltage symbol	Part no.
All voltages	None	SY100-82-1

#### With light

Rated voltage	Voltage symbol	Part no.
24 VDC	24 V	SY100-82-3-05
12 VDC	12 V	SY100-82-3-06
100 VAC	100 V	SY100-82-2-01
200 VAC	200 V	SY100-82-2-02
110 VAC (115 VAC)	110 V	SY100-82-2-03
220 VAC (230 VAC)	220 V	SY100-82-2-04

#### Circuit diagram with light




### Fitting and Silencer Part No. for P, R Ports When Using Valve as an Individual Unit

Part no. for one-touch fitting for 1(P) port and silencer/one-touch fitting for 3(R) port

Series	(1) One-touch fitting for 1(P) port	(2) For 3(R) port	
		Silencer	One-touch fitting
VQZ100	KQ2H06-M5A	AN120-M5	KJS04-M5A
VQZ200	KQ2S06-01AS	INA-25-46	IN-457-32L (for $\phi 6$ )
VQZ300	KQ2H08-02AS	AN101-01	KQ2H06-01AS

The diameter of the above fitting and silencer is the maximum diameter to in the EXH port.







# VQZ Series

## Specific Product Precautions 4

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 3 to 9 for 3/4/5 Port Solenoid Valve Precautions.

### One-touch Fittings Replacement

#### ⚠ Caution


The built-in fittings on the manifold can be changed easily. Simply remove the corresponding valve and take out the fitting clip underneath.

Take out the clip with a screwdriver, etc., then replace the fittings. About mounting the fittings, after inserting the fitting until it stops, then put the clip into the prescribed position.

VQZ200: Horizontally clipped to the valve body

VQZ100/300: Vertically clipped to the valve body

#### ■ Valve




#### Valve Clip Part No. (10 pcs. included)

Series	Part number
VQZ100	VQZ100-2-FC
VQZ200	VQZ200-2-FC
VQZ300	VQZ300-2-FC

#### ■ Manifold base

#### Base Clip Part No. (10 pcs. included)

Series	Part number
VV3QZ15	VQZ100-5-FC
VV3QZ25	VQZ200-5-FC
VV3QZ35	VQZ300-5-FC



#### Precautions

When pulling the fitting assembly away from the valve base, remove the clip, then connect a tube or plug (KQ2P-□□) with the One-touch fitting and pull it out holding the tube or plug. Do not hold the release bushing to avoid damage.

### DIN Rail Removal/Mounting


#### ⚠ Caution

#### 1. Removing

- Loosen the clamp screw on the (a) side of both ends of the manifold.
- Lift the (a) side → of the manifold off the DIN rail and slide it in the direction of the (b) side.

#### 2. Mounting

- Catch the hook of the DIN rail bracket on the (b) side on the DIN rail.
- Push side (a) onto the DIN rail and tighten the clamp screw. The proper tightening torque for screws is 0.3 to 0.4 N·m.




### Valve Mounting

#### ⚠ Caution

- After confirming the gasket is correctly placed under the valve, securely tighten the bolts with the proper torque shown in the table below.

Model	Proper tightening torque
VQZ100	0.13 to 0.19 N·m
VQZ200	0.25 to 0.35 N·m
VQZ300	0.5 to 0.7 N·m




### VQZ100 Piping Direction Replacement

#### ⚠ Caution

- How to replace the port direction

Fitting and port plug are modules. After removing the clip with a flat head screwdriver, take out the fitting and port plug. The piping direction (side or top) can be altered by exchanging the fitting and port plug. During exchange, insert the fitting and the port plug until they contact the wall, then, insert the clip to specified position.




#### Precautions

The clip length for the valve and the base are different. Fitting may detach if the incorrect clip is used.

- Valve piped on top can be operated independently by using PR plate.

(Refer to the below part numbers when placing an order.)



VQZ100-12A (Standard)  
VQZ100-12B (External pilot type)  
\* 2 set screws are included.

SYJ

VQZ

VP

VG

VP3